

Tote Sprayer System Quick Start Guide

1. **Prime the suction line with water** With the spray system off, fill the suction hose (from the pump inlet to the tote connection) completely with clean water. This displaces all air in the line, ensuring the pump can prime properly without cavitation.
2. **Connect to the tote** Attach the water-filled suction hose securely to the bottom outlet of the tote. Double-check that no air can enter the line — use tight fittings and keep everything submerged or sealed.
3. **Run in recirculation mode** Start the spray system in recirculation mode. This circulates the sealer, removes any remaining air, and fully primes the pump. Run for **3–4 minutes** to achieve a complete prime. **Important:** Do not over-circulate — excessive agitation can introduce foam or air pockets, which may cause uneven application, reduced pressure, or pump issues.
4. **Switch to spray mode** Once primed and stable, turn the ball valve from recirculation to spray mode. Begin applying sealer evenly to the surface, adjusting your pace for consistent thickness.