Instruction

Fuse Installation for LineLazer V 250SPS and 250DC Self-Propelled Line Striper


3A5189A
EN

For initial use - fuse installation.

Important Safety Instructions
Read all warnings and instructions in this manual and in the sprayer operation manual. Save these instructions.

Fuse Installation Process

1. Remove fuse cover (1).
2. Use needle-nose pliers (2) to install new fuse (3).
3. Replace cover (1).



Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call 1-800-690-2894 to identify the nearest distributor.

All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A5189
Graco Headquarters: Minneapolis
International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2017, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision A, April 2017